

X2 TRANSPONDER

QUICK START GUIDE



IMPORTANT!

Before you mount your X2 Transponder to your vehicle, make sure you:


- Register your X2 Transponder to your account
- Activate the subscription on your X2 Transponder

Without these 2 steps your X2 Transponder will NOT work

REGISTER



Go to account.mylaps.com



WHAT'S IN THE BOX?









2 Transponder

X2 RaceKey

ransponder H

Data Cable

Extra accessories for Direct Power X2 Transponder







Racekey Mount Cabl

Property to 12VDI power source cab

X2 RaceKey Mount





IN CASE YOU ENCOUNTER ANY ISSUES, PLEASE CONTACT YOUR LOCAL OFFICE MYLAPS EMEA Office Haarlem, The Netherlands

+31 (0)23 760 0100

MYLAPS Americas Office Atlanta, USA


+1 678 816 4000

info.americas@mylaps.com


ACTIVATE




Log in with same account details











4 hours charging = 5 days racing

MYLAPS Japan Office Tokyo, Japan

+81 3 6418 8209

info.japan@mylaps.com

MYLAPS APAC Office


Sydney, Australia +61 2 9533 1100

▼ info.asia.pacific@mylaps.com

MYLAPS Asia Office Selangor, Malaysia

· +60 3 5613 1235

info.asia@mylaps.com



After disconnecting transponder and RaceKey, check the top of the transponder.

4 times flashing green = 5 days racing 3 times flashing green = 4 days racing 2 times flashing green = 3 days racing 1 time flashing green = 2 days racing

Flashing red = battery for less than 1 day









CAR & KART











FOR DIRECT POWER TRANSPONDERS ONLY





MYLAPS.COM